




# HERKULES PLUS

Instrukcja montażu  
Installation instruction  
Инструкция монтажа

## 2(4)x25kg



tel. 22 818 77 22



1

$D \leq 600\text{mm}$     $G = 16 - 40\text{mm}$



G [mm]	16	18	22	25	28	32	40
x	2	2	3	3	4	4	6

2 A




$$D[\text{mm}] = \frac{L[\text{mm}] - x - 5}{2}$$

2 B




$$D[\text{mm}] = \frac{L[\text{mm}] - 2x - 8}{4}$$





3




4 A




4 B





5



7



6



1:1




# HERKULES PLUS

Instrukcja montażu  
Installation instruction  
Инструкция монтажа

## 2(4)x40kg



tel. 22 818 77 22



1

$D \leq 750\text{mm}$   $G = 16 - 40\text{mm}$



G [mm]	16	18	22	25	28	32	40
x	2	2	3	3	4	4	6

2 A




$$D[\text{mm}] = \frac{L[\text{mm}] - x - 5}{2}$$

2 B




$$D[\text{mm}] = \frac{L[\text{mm}] - 2x - 8}{4}$$






3




4 A





4 B




5



7



6



1:1